

AVAT/AVATM (IKT/IKTM)

Part-turn actuator spares Material Part No.

Item	Part Name	Part No.	Item	Part Name	Part No.
1.1	Power Board	B0001-1	5.2	Stator	B0007
1.2	Transformer	B0001-2	6	Base and Coupling	B0008
2.1	Main board	B0002	7	Terminal Cover	B0009
2.2	Key Board	B0003	8	Terminal Compartment	B0010
3	Control Case	B0004	9	Lever	B0011
4	Switch and push button	B0005	10	Hall board	B0012
5.1	Rotor	B0006			

Part-turn actuator spares drawing

